


X-RAY RAY68 AC RUNYES Micro Switches

To turn on the wireless remote control, select the correct switch position according the picture. For turned on, the position are (1 and 2)up



To adjust the correct equipment voltage select the correct switch position according the picture. For 120V, the position are (1)up, (2)down, (2)down

WARNING: THIS PROCEDURE MUST BE DONE FOR A SPECIALIZED TECHNICIAN. WE ARE NOT RESPONSIBLE FOR ANY ACIDENT OR DAMAGE DURING THE PROCEDURE